

KINDS OF TOOLS

CONICAL POINT



Used for general demolition work where penetrative breaking is required

CHISEL



Used same as cones, but also for cutting actions, as benching and trenching

PYRAMID TOOL



Used for works where increased breakout forces are required

WIDE CHISEL



Used for increased productivity in softer materials

X-TYPE



Used for works in soft or high dust operations

BLUNT TOOL



Used for impact breaking, secondary breaking and also scaling in mines and tunnels